

Dismantling your Xbox

What you will need:
Torx driver sizes 10 and 20

There are 6 Screws holding the Xbox case together. Use a Torx driver size 20 to remove them.



Once unscrewed pull the top of the Xbox case off. You will see the DVD drive and Hard drive. Unplug the power and IDE ribbon cable from both the DVD drive and hard drive. There is 1 screw holding the hard drive tray and 2 screws holding the DVD drive tray. Once removed you will be able to lift out the hard drive tray first and then the DVD drive tray.



Once you remove both the DVD drive tray and hard drive tray you will see the Xbox motherboard and power supply. You will need to unplug the fan, the controller ports, Power/Eject buttons and power supply plugs from the motherboard. There are 11 screws holding in the motherboard.



Lift up on the front of the motherboard and gently pull towards you to remove the motherboard.

Now your Xbox is in pieces and ready to be modded.

Tutorial by:

RustyDog

www.get-modded.com